# beachside oak

Comfort | CC0806

#### Reducer

WP01060\_00006RD



0.708 in.

Used to transition between two flooring heights, providing a smooth change.

TRIM LENGTH (in.)

94.5

TRIM HEIGHT (in.)

0.39

TRIM WIDTH (in.)

1.77



#### T-Mold

WP01060\_00006TM



Covers the seam between two floors of equal height.

TRIM LENGTH (in.)

94.5

TRIM HEIGHT (in.)

0.39

TRIM WIDTH (in.)

1.71



### Quarter Round

WP01060\_00006QR

Installed along the base of the wall to cover gaps and add a decorative touch.

TRIM LENGTH (in.)

94.5

TRIM HEIGHT (in.)

0.708

TRIM WIDTH (in.)

0.708



2.07 in.

#### Threshold

WP01060\_00006BT

1.73 in.

2.01 in.

Creates a smooth transition between rooms or doorways, often at entryways.

TRIM LENGTH (in.)

94.5

TRIM HEIGHT (in.)

0.35


TRIM WIDTH (in.)

1.73



### Flush Stair Nose

WP01060\_00006FS



TRIM LENGTH (in.)

94.5

TRIM HEIGHT (in.)

0.75


TRIM WIDTH (in.)

2.07



## Overlap Stair Nose

WP01060\_00006OS



TRIM LENGTH (in.)

94.5

TRIM HEIGHT (in.)

1.5

TRIM WIDTH (in.)

2.01



# beachside oak



Comfort | CC0806





Stair Treads Tip: Complete the look on the top stair with a flush or overlap stair nose.